



FOX EOS 5000

NO.	PARTS NAME	12	LINE ROLLER	24	ROTOR BODY	36	OSCILLATING SHAFT	48	ANTI-REVERSE SWITCH	60	HANDLE SCREW	72	SPRING	84	SCREW	96	SPRING
1	FRONT CLUTCH KNOB	13	BEARING	25	BAIL ARM	37	BEARING	49	PLATE	61	HANDLE WASHER	73	SLIDE	85	FREE SPOOL ARM	97	PIP
2	SPOOL	14	LINE ROLLER PLATE	26	INSERT	38	MAIN SHAFT	50	SHAFT	62	SCREWS	74	COVER PLATE	86	FREE-SPOOL OUTER ARM	98	FREE-SPOOL OUTER ARM
3	WASHER	15	SCREW	27	BAIL ARM PLATE	39	PINION	51	SCREW	63	SCREW COVER	75	MAIN BODY	87	SHIM	99	REAR DRAG KNOB
4	CLICKER	16	ROTOR COVER PLATE	28	SCREW	40	BEARING PLATE	52	TOOTH HOLDER	64	SIDE PLATE	76	COVER PLATE	88	CLUTCH HOLDER	100	SINGLE HANDLE
5	CLICKER PLATE	17	BUSH	29	SCREW COVER	41	BEARING	53	TOOTH BUSH	65	CLICKER SPRING	77	SCREW	89	CLUTCH PART		
6	ROTOR NUT	18	SCREW COVER	30	SCREW	42	BEARING HOLDER	54	TOOTH	66	CLICKER SPRING RETAINER	78	FREE-SPOOL LEVER PLATE	90	CLUTCH PART		
7	NUT RETAINER PLATE	19	SCREW	31	PLATE	43	ANTI-REVERSE BEARING	55	TOOTH PLATE	67	BEARING	79	SPRING	91	CLUTCH PART		
8	SCREW	20	SPRING HOLDER	32	SHIM	44	SPRING	56	SCREW	68	SHIM	80	FREE-SPOOL BOSS	92	CLUTCH PLATE		
9	SCREW	21	SPRING	33	SCREWS	45	TORSION SPRING	57	COVER PLATE	69	MAIN GEAR	81	BEARING	93	SPRING		
10	LINE ROLLER BODY	22	LEVER	34	BEARING	46	ANTI-REVERSE LEVER	58	SCREW	70	BEARING	82	TORSION SPRING	94	THREADED INSERT		
11	LINE ROLLER HEAD	23	PUSH ARM	35	GEAR	47	SCREW	59	SIDE COVER	71	PLATE INSERT	83	SCREW	95	RETAINER PLATE		