



FOX EOS 12000FS

Exploded Drawing Version 1.0

No	Parts Name	No	Parts Name	No	Parts Name	No	Parts Name	No	Parts Name	No	Parts Name
1	DRAG KNOB PLATE	21	LINE ROLLER BALL BEARING	41	BAIL ARM COVER PLATE SCREW	61	OSCILLATING SHAFT ROLLER	81	SIDE PLATE	101	HANDLE SHAFT
2	DRAG KNOB	22	LINE ROLLER	42	BAIL ARM COVER PLATE SCREW	62	OSCILLATING SHAFT GEAR	82	MAIN BODY SCREW	102	HANDLE KNOB CAP
3	SPOOL	23	LINE ROLLER WASHER	43	RUBBER WIPER HOUSING	63	OSCILLATING SHAFT	83	MAIN BODY SCREW	103	HANDLE SCREW CAP WASHER
4	GRIT GUARD	24	LINE ROLLER HOUSING	44	BAIL ARM ROTATING LINK	64	OSCILLATING SHAFT ROLLER	84	MAIN BODY SCREW COVER	104	HANDLE SCREW CAP
5	CLUTCH RETAINER SPRING	25	LINE ROLLER HOUSING SCREW	45	BAIL ARM	65	OSCILLATING SHAFT END PLATE	85	OSCILLATING SLIDER HOUSING	105	OSCILLATING PARTS COVER
6	METAL CLUTCH PLATE	26	LINE ROLLER HOUSING SCREW	46	BAIL ARM ROTATING LINK SCREW	66	OSCILLATING SHAFT BALL BEARING	86	OSCILLATING SLIDER BEARING	106	OSCILLATING PARTS COVER SCREW
7	FIBRE CLUTCH PLATE	27	LINE ROLLER HOUSING SCREW COVER	47	BAIL ARM ROTATING LINK SCREW COVER	67	LINKAGE GEAR 2 SCREW	87	OSCILLATING FOLLOWER BUSH CAP	107	BODY COVER
8	METAL CLUTCH PLATE	28	BAIL ARM TRIGGER SPRING PIN	48	MAIN SHAFT	68	FREE SPOOL CLICKER SPRING RETAINER	88	OSCILLATING FOLLOWER BUSH CAP SCREW	108	BODY COVER PLATE
9	FIBRE CLUTCH PLATE	29	BAIL ARM PIN	49	PINION GEAR	69	LINKAGE GEAR 2 CLICKER GEAR	89	OSCILLATING FOLLOWER	109	BODY COVER SCREW
10	METAL CLUTCH PLATE	30	BAIL ARM TRIGGER SPRING	50	PINION GEAR BEARING LOCATION SCREWS	70	LINKAGE GEAR 2	90	OSCILLATING FOLLOWER BUSH	110	DETENT SPRING
11	FIBRE CLUTCH PLATE	31	ACTIVATION ROD	51	PINION GEAR BALL BEARING	71	LINKAGE GEAR 2 SHIM	91	OSCILLATING SUPPORT SHAFT WASHER	111	DETENT
12	SHIM	32	RUBBER WIPER	52	ANTI-REVERSE BEARING HOUSING ASSEMBLY	72	FREE SPOOL CLICKER SPRING	92	OSCILLATING SUPPORT SHAFT SCREW	112	FREE SPOOL COVER PLATE
13	CLICKER GEAR	33	RUBBER WIPER HOUSING	53	ANTI-REVERSE BEARING HOUSING SCREWS	73	ANTI-REVERSE LINKAGE CAM	93	OSCILLATING SUPPORT SHAFT	113	FREE SPOOL COVER PLATE SCREW
14	CLICKER GEAR WASHER	34	BAIL ARM COVER PLATE SCREW	54	PINION GEAR BALL BEARING	74	ANTI-REVERSE SWITCH	94	FREE SPOOL ADJUSTER SPRING RETAINER	114	FREE SPOOL COVER PLATE SCREW
15	ROTOR NUT	35	BAIL ARM COVER PLATE SCREW	55	PINION GEAR SHIM	75	ANTI-REVERSE SWITCH SCREW	95	FREE SPOOL ADJUSTER CLICKER SPRING	115	FREE SPOOL LOCKING COG WASHER
16	ROTOR NUT LOCK SCREW	36	BAIL ARM TRIGGER SIDE PLATE	56	LINKAGE GEAR 1 SLEEVE	76	ANTI-REVERSE SWITCH SPRING	96	MAIN DRIVE EAR BALL BEARING	116	FREE SPOOL LOCKING COG
17	ROTOR LOCK PLATE	37	ROTOR CAP	57	LINKAGE GEAR	77	MAIN BODY	97	MAIN BODY INSERT	117	FREE SPOOL SHAFT E-CLIP
18	ROTOR CAP SCREW	38	ROTOR	58	OSCILLATING SHAFT SHIM	78	MAIN DRIVE GEAR	98	HANDLE STEM	118	FIBRE WASHER
19	LINE ROLLER AND BAIL ARM LINK	39	ROTOR RING	59	OSCILLATING SHAFT BALL BEARING	79	MAIN DRIVE GEAR SHIM	99	HANDLE SHIM	119	METAL WASHER
20	LINE ROLLER WASHER	40	BAIL ARM COVER PLATE	60	OSCILLATING SHAFT BUSH	80	MAIN DRIVE GEAR BALL BEARING	100	HANDLE KNOB	120	FIBRE WASHER
										101	HANDLE SHAFT
										102	HANDLE KNOB CAP
										103	HANDLE SCREW CAP WASHER
										104	HANDLE SCREW CAP
										105	OSCILLATING PARTS COVER
										106	OSCILLATING PARTS COVER SCREW
										107	BODY COVER
										108	BODY COVER PLATE
										109	BODY COVER SCREW
										110	DETENT SPRING
										111	DETENT
										112	FREE SPOOL COVER PLATE
										113	FREE SPOOL COVER PLATE SCREW
										114	FREE SPOOL COVER PLATE SCREW
										115	FREE SPOOL LOCKING COG WASHER
										116	FREE SPOOL LOCKING COG
										117	FREE SPOOL SHAFT E-CLIP
										118	FIBRE WASHER
										119	METAL WASHER
										120	FIBRE WASHER
										121	HANDLE SHAFT
										122	FREE SPOOL PLATE
										123	FREE SPOOL THREADED ADJUSTER
										124	FREE SPOOL SHAFT
										125	FREE SPOOL SHAFT RETAINER
										126	FREE SPOOL KNOB
										127	ENGAGE LEVER SCREW
										128	ENGAGE LEVER
										129	ENGAGE LEVER SPRING
										130	SUPPORT PLATE SCREW
										131	SUPPORT PLATE
										132	PIVOT LINKAGE
										133	PIVOT LINKAGE BALL BEARING
										134	PIVOT LINKAGE TENSION SPRING
										135	FREE SPOOL LOCKING COG WASHER
										136	FREE SPOOL SWITCH PART 1
										137	FREE SPOOL SWITCH CENTRE
										138	FREE SPOOL SWITCH PART 2
										139	FREE SPOOL SWITCH SCREW
										140	FREE SPOOL SWITCH LONG SCREW